



VERSALOUPE™**10x LED Lighted Focusing Loupe*****Instructions for Use******Installing the Battery***

Turn loupe over and locate the battery cover inside acrylic base. Unscrew cover and remove as shown below. Install one CR2032 coin cell battery with the correct polarity. Reattach battery door and secure with screw.


**REMOVING
BATTERY
DOOR****REPLACING
BATTERY
DOOR**

NOTE: Battery may be difficult to remove by hand. Needle nose pliers are recommended.

WARNING: INSPECT ALL BATTERIES FOR SIGNS OF CORROSION OR LEAKAGE. DO NOT EXPOSE TO FIRE OR EXCESSIVE HEAT. USE ALKALINE BATTERIES ONLY, RECHARGEABLE BATTERIES NOT RECOMMENDED. INSERT ALL BATTERIES IN THE DIRECTION INDICATED.


Activating LED Light

Slide switch to turn on/off LED.



Focusing Loupe

Place loupe over viewing subject and turn focusing ring until image is sharp.



Cleaning Your Magnifier

Clean lens with a soft, clean microfiber cloth by rubbing gently in a circular motion. Moisten the lens cloth with water if necessary. Do not use harsh chemicals, solvents or abrasives as they may damage the lens.

FIRE HAZARD: KEEP MAGNIFIER AWAY FROM DIRECT SUNLIGHT TO PREVENT ACCIDENTAL FIRE.

CAUTION: VIEWING THE SUN CAN CAUSE PERMANENT EYE DAMAGE. DO NOT VIEW THE SUN WITH THIS ITEM. DO NOT PLACE THE LED LIGHTS DIRECTLY ON YOUR EYE AS THIS MAY CAUSE DAMAGE AS WELL.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.

In the U.S.A.

Phone: 1-631-963-5000

Email: info@carson.com

In the E.U.

Phone: +44 (0) 1938 557440

Email: eusupport@carson.com

In the U.K.

Phone: +44 (0) 1938 557440

Email: uksupport@carson.com

For warranty information, visit www.carson.com/warranty